
Compact cooking set with mini colander_4th Size: 144mm x 380mm Aug-04-2013



- Keep away from fire.
- Do not drop or expose product to shock. Damage may be caused.
- When using as a grinding plate, do not use metal spoons or sharp tools as they may cause damage to the protruded surface of the masher.
- If any of the items appear to cause an allergic reaction to the baby's skin, cease using and consult a doctor immediately.

3

Washing and sterilizing

- may hurt the product surface. Use
- washing. Follow the instructions of
- and pour enough water inside and heat the water until it boils. Place tableware inside for around 2~3 minutes. (Exposure to boiling water for too long may cause
- When bleaching the product, apply bleaching agents that are suitable to kitchenware.
- Do not bleach for more than 30~40 minutes. Follow the bleaching agent instructions properly.
- When using sterilizing agent or anti-bacteria agent, make sure to follow the caution items accordingly.
- When using dish washer, make sure to follow the instruction properly.
- Food color may remain on the product surface even after washing. This does not affect normal use of product.

6

